

**BALTIMORE AIRCOIL COMPANY**Baltimore Aircoil International nv › Industriepark, Zone A › 2220 Heist-op-den-Berg › Belgium › [www.BaltimoreAircoil.eu](http://www.BaltimoreAircoil.eu)

# CAREL PCO5 COMMUNICATION CARD REPLACEMENT

## 1) REMOVE THE PCO5 FROM THE ELECTRICAL CABINET


Shut down the unit (use the main power switch) and open the door of the electrical cabinet. Remove all connectors from the PCO5. *Note: the markings on the plugs correspond to the markings on the PCO connectors.*

Remove the PCO5 from its rail.



## 2) OPEN THE PCO5


Gently remove the plastic cover from the PCO5 to gain access to the communication card. You can now remove the communication card.





**BALTIMORE AIRCOIL COMPANY**

Baltimore Aircoil International nv › Industriepark, Zone A › 2220 Heist-op-den-Berg › Belgium › [www.BaltimoreAircoil.eu](http://www.BaltimoreAircoil.eu)



### 3) REINSTALLATION

Follow this procedure backwards to reinstall the communication card, close the PCO5 and reinstall it in the electrical cabinet.